
# FullSpectrum 6 HD



instruction manual

Edition May 2021 Version 2.0





Fixture code:
Purchase date:
Dealer:
Address:
Suburb:
Country:
Phone / Fax:

Please note in the space provided above the relative service information of the model and the retailer from whom you purchased your **LEDko FullSpectrum 6 HD**: this information will assist us in providing spare parts, repairs or in answering any technical enquiries with the utmost speed and accuracy.

**WARNING:** the security of the fixture is granted only if these instructions are strictly followed; therefore it is absolutely necessary to keep this manual.

# Index

1. P	Packaging and transportation	Pag. 5
1	<b>1.1.</b> Packaging	Pag. 5
1	<b>1.2.</b> Transportation	Pag. 5
2. 0	General information	Pag. 5
2	<b>2.1</b> Safety informations	Pag. 5
2	<b>2.2</b> Warranty conditions	Pag. 6
2	<b>2.3</b> EC Norms	Pag. 6
3. F	Product specifications	Pag. 7
3	<b>3.1</b> Technical characteristics	Pag. 7
3	<b>3.2</b> Dimensions	Pag. 7
3	<b>3.3</b> Unit's main components	Pag. 8
3	<b>3.4</b> Back panel description	Pag. 9
4. I	Installation	Pag. 10
	<b>4.1</b> Optical Installation	<u> </u>
	<b>4.2</b> Mechanical installation	•
	<b>4.3</b> Safety chain	<u> </u>
4	<b>4.4</b> Adjusting unit's tilt	Pag. 11
	Powering up	
	<b>5.1</b> Operating voltage and frequency	
5	<b>5.2</b> Connection to mains power	Pag. 12
	Control signal connections	
6	<b>6.1</b> Control signal connection by XLR5 plugs	Pag. 13
	Furning on the projector	
7	<b>7.1</b> DMX address of the unit	Pag. 14
	DMX Chart	
	<b>8.1</b> DMX Chart: 16, 7, 1 channels	
8	<b>8.2</b> DMX Chart: Studio	Pag. 18
9. D	Display panel functions	Pag. 20
9	<b>9.1</b> Quick guide to menu	Pag. 20
	<b>9.2</b> Rapid count	
	<b>9.3</b> Main functions menu	<del>_</del>
	<b>9.4</b> Measure	9
	<b>9.5</b> Color presets	
	<b>9.6</b> Special functions of the fixture	
9	<b>9.7</b> Error messages	Pag. 28
10.	. Accessories and spare parts	Pag. 29

11. Maintenance	Pag. 31
<b>11.1</b> Firmware update	Pag. 31
11.2 Periodic cleaning	Pag. 31
11.3 Periodic controls	Pag. 31
<b>11.4</b> Fuses	Pag. 31
12. F.A.Q. and answers	Pag. 32

Congratulations on having purchased a **Coemar** product. You have assured yourself of a fixture of the highest quality, both in componentry and in the technology used. We renew our invitation to you to complete the service information on the previous page, to expedite any request for service information or spares (in case of problems encountered either during, or subsequent to, installation). This information will assist in providing prompt and accurate advice from your **Coemar** service centre. Following the instructions and procedures outlined in this manual will ensure the maximum efficiency of this product for years to come.

# 1. Packaging and transportation

#### 1.1 Packaging

Open the packaging and make sure that no part of the equipment has suffered any damage during the transportation. In case of damage to the fixture, contact your currier and your supplier immediately by telephone, fax or email, and inform them you will formally notify them in writing through registered letter.

#### **Packing list**

Ensure the packaging contains:

- 1 Reflection LEDko FullSpectrum 6 HD
- 1 Instruction manual
- 1 Main power plugs

#### **1.2** Transportation

The **LEDko FullSpectrum 6 HD** should be transported in either its original packaging or in an appropriate flight case.

#### 2. General information

#### 2.1 Safety informations

#### Fire prevention:



- **1.** Never locate the fixture on any flammable surface.
- 2. Minimum distance from flammable materials: 0,5m.
- 3. Minimum distance from the closet illuminable surface: 0,5m.
- **4.** Replace any blown or damaged fuse only with those of identical values. Refer to the schematic diagram if there is any doubt.
- **5.** Connect the projector to mains power protected by a thermal magnetic circuit breaker.

#### **Prevention from electric shock:**



- 1. Presence of high voltage inside of the fixture. Insulate the projector from mains supply before opening or performing any function which involves touching the inside of the fixture, including lamp replacement.
- **2.** For the connection to the mains, adhere strictly to the guidelines outlined in this manual.

- **3.** The level of technology of **LEDko FullSpectrum 6 HD** requires the use of specialised personnel for all service applications; refer all work to your authorised **Coemar** service centre.
- **4.** A good earth connection is essential for the proper functioning of the projector. Never connect the fixture if there is no earth connection.
- **5.** Mains cables must not come into contact with other cables.
- **6.** Do not operate the projector with wet hands or in an area where water is present.
- **7.** The fixture must never be located in an exposed position, or in areas of extreme humidity.

#### Safety:



- **1.** The projector must always be installed with bolts, clamps, or other fixing devices which are suitably rated to support the weight of the projector.
- 2. Always use a secondary safety fixing device with chain or steel wire of a suitable rating to sustain the weight of the unit in case of failure of the principal fixing point.
- **3.** The external surfaces of the unit, at various points, may reach 60°C. Never handle the unit until at least 10 minutes have elapsed since the LED was turned off.
- **4.** Never install the fixture in an enclosed area lacking sufficient air flow; the room temperature must not exceed 35°C.
- 5. The projector contains electronic and electrical components which must under no circumstances be in contact with water, oil or any other liquid. Failure to do so will compromise the proper functioning of the projector.

#### 2.2 Warranty conditions

- **1.** The fixture is under warranty for 36 months from the purchase date against factory defections.
- **2.** Damage ought to unskillfulness, inappropriate use, or lack of suggested maintenance are excluded from the warranty.
- **3.** Warranty expires when the projector is opened by unauthorized personnel.
- **4.** Warranty doesn't include the replacement of the fixture.
- **5.** Serial number and model of the fixture are necessary to retrieve informations and assistance from the dealer.

#### 2.3 EC Norms


The projector meets all fundamental applicable EC requirements.

# 3. Product specifications


#### **3.1** Technical characteristics

Power supply	90-230Vac, 50-60Hz
Maximum current	1.06 A at 230 V, 2.71 A at 90 V
Power factor	Cos = 0.9
Power consumption	220 watt
Color temperature	RGBWLA, with pure color mixing throughout the field and all whites from 2700 to 6500 K
Weight (without optic)	6kg - 13.2lbs
Maximum ambient temperature	+35°C / +95°F
IP rating	IP20

#### **3.2** Dimensions




**3.3.** Unit's main components




	Components description								
A	Adjustable yoke								
В	Iris (optional)								
С	Gobo holder (optional)								
D	Lens adjusting handles								
E	Yoke locking handle								
F	Gel frame locking spring								
G	Profile blade								
Н	Interchangeable optic								


#### 3.4 Back panel description





## 4. Installation

#### 4.1 Optical installation



















Remove the frontal cap by loosening the upper and lower screws enough to free the cap itself, set the optic's flange tilted about 60°. Insert the optic's flange into the body's receptacle and turn the optic 60° until it is firmly assembled to the projector body, free to rotate but not free to detach itself from the body. Ensure the optic to the body by tightening the two screws previously loosened.


#### Warning!!

When the protective cap is removed, never lean the fixture facing down.

The front lens can be seriously damaged.









#### 4.2 Mechanical installation

**LEDko FullSpectrum 6 HD** may be hung from an appropriate structure in any position or on tripode. If hanging the fixture from a lighting truss or similar, we recommend the use of an appropriate clamp "A", as shown in the following diagram.



#### 4.3 Safety chain

When hanging it is recommended to use a safety chain, as required by current legislation. The safety chain must pass through the handles of the unit and then attached to the structure. If using steel cables and chains not 's production, make sure they are suitable to support the weight of the unit according to normative UL/ETL (required: the weight of 6 complete devices for at least one hour).



#### 4.4 Adjusting unit's tilt

In order to adjust the tilt of the unit simply loose the side handle adjust the tilt and lock the yoke by tightening the handle again.

# 5. Powering up

#### **5.1** Operating voltage and frequency

The unit may operates at voltages ranges from 90 to 250VaC at a frequency of 50 or 60 Hz. It is not needed to effect any setup procedures: **LEDko FullSpectrum 6 HD** will automatically adjust its operation to suit any frequency or voltage within this range.

# **5.2** Connection to mains power Mains cable characteristics

The mains cable provided is thermally resistant, complying to the most recent International standards.


**Note:** in case of cable replacement, similar cable with comparable thermal resistant qualities must be used exclusively (cable 3 X 1,5 ø external 10 mm, rated 300/500V, tested to 2 KV, operating temperature -40°C + 180°C, Coemar cod. CV5311).

#### **Connection to mains power**

**LEDko FullSpectrum 6** is equipped with two power connectors, one as input and one as output, which can be used to feed up to 8 (at 230 VAC) or 4 (90 VAC) fixtures.

The max absorption of **LEDko FullSpectrum 6 HD** is reported in the following table:

- 230 VaC 1.06 A constant during normal exercise.
- 90 VaC 2.71 A constant during normal exercise.




#### Warning!!

- The use of a thermal/magnetic circuit breaker is recommended. Strict adherence to regulatory norms is strongly recommended.
- **LEDko FullSpectrum 6 HD** should not be powered through a dimmer as this may damage the internal switching power supply.
- Prior to connecting the device to mains power, ensure that the mains characteristics are within the recommended range for the use of **LEDko FullSpectrum 6 HD**.
  - All cabling and connections should be carried out by a suitably qualified personnel.

# 6. Control signal connections

#### **6.1** Control signal connection by XLR5 plugs

The digital control signal is transmitted to the projector via a two pole cable screened in according to the International standards for DMX 512 data transmission. The connection must be serial, using connectors XLR5 male and female located on the back of **LEDko FullSpectrum 6 HD** labelled DMX512 IN e OUT.



#### Warning!

Make sure that screening and conductors are not in contact one another or with the metal housing of the connector.

Pin#1 and housing must never be connected to the power supply unit.

# 7. Turning on the projector

After having followed the preceding steps described, proceed with the power supply and turn on the projector connecting it to the mains power.

The software version installed on the internal microprocessors will be shown on the display, suddenly it will show the current DMX addressing. If the address blinks, it means that the DMX signal has not been received. Check the connection cable and the mixer functioning.

#### 7.1 DMX address of the unit

Each projector can use 16/7/5/1 or Studio mode for its complete operation and is controlled by a DMX 512 signal.

#### **DMX addressing**

When powered up initially, each projector will show A001, which indicates DMX address 001; for example, when set at 16 channels a projector thus addressed will respond to commands of channel 1 to 16 from your DMX 512 controller. A second unit must be addressed as A017, a third one as A033 and so on. The operation must be carried out on every **LEDko FullSpectrum 6 HD** which has an address different from A001.

#### **Altering the DMX address:**

- **1.** Press the + or button until the display shows the required DMX address. The digits on the display will blink to indicate that the variation has not been registered.
- 2. Press the enter key to confirm your selection. The digits on the display panel will cease to blink and the projector will now respond to the new address.

**Note:** by holding the + or - button down the scrolling will be faster; thus allowing a faster selection



#### Warning!!

If you alter the DMX address with no DMX signal connected, the digits on the display panel will continue to flash even after you have pressed ENTER button to confirm the address.

# 8. DMX chart

#### **8.1** DMX Chart 16, 7, 1 channels

ch	ann	_	function	type of control	effect	de	cir	nal	perd	:en	tage
16	7	1	1		******		-		Pon		
1	1	1 <sup>2</sup>	master dimmer	proportional	adjust luminous output intensity from 0 to 100%	0	-	255	0%	-	100%
2	2	-	red	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
3	3	-	green	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
4	4	-	blue	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
5	5	-	white	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
6	6	-	lime	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
7	7	-	amber	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
				step	no effect	0	-	9	0%	-	4%
				proportional	variable speed strobing effect, from slow to fast	10	-	57	4%	-	22%
				step	stop strobe	58	-	59	23%	-	23%
				proportional	sequenced pulse effect, slow closing, fast opening (variable speed pulsing, from slow to fast)	60	-	108	24%	-	42%
				step	stop strobe	109	-	110	43%	-	43%
8	-	-	strobe	proportional	sequenced pulse effect, fast closing, slow opening (variable speed pulsing, from slow to fast)	111	-	159	44%	-	62%
				step	stop strobe	160	-	161	63%	-	63%
				proportional	random strobe effect with variable speed from slow to fast	162	-	207	64%	-	81%
				step	stop strobe	208	-	209	82%	-	82%
				proportional	random strobe effect with variable speed from slow to fast	210	-	255	82%	-	100%
9	-	-	dimmer fine	proportional	fine dimmer control 16 bit	0	-	255	0%	-	100%
					no effect	0	-	9	0%	-	4%
				_	600 Hz	10	-	84	4%	-	33%
				step	fan at low-noise speed	85	-	96	33%	-	38%
					fan at studio mode	97	-	108	38%	-	42%
10	-	-	special functions		fan at auto-silent speed	109	-	120	43%	-	47%
				proportional	fan speed control	121	-	133	47%	-	52%
					enables the automatic display blackout	134	-	185	53%	-	73%
				step	disables the automatic display blackout	186	-	199	73%	-	78%
					no effect	200	-	255	78%	-	100%

					no effect	0	-	9	0%	-	4%
					COR01 - GELS RED 1	10	-	34	4%	-	13%
					COR02 - GELS RED 2	35	-	59	14%	-	23%
					COR03 - GELS RED 3	60	-	84	24%	-	33%
					COR04 - GELS RED 4	85	-	109	33%	-	43%
11¹	-	-	red tone	step	COR05 - GELS RED 5	110	-	134	43%	-	53%
					COR06 - GELS RED 6	135	-	159	53%	-	62%
					COR07 - GELS RED 7	160	-	184	63%	-	72%
					COR08 - GELS RED 8	185	-	209	73%	-	82%
					COR09 - GELS RED 9	210	-	234	82%	-	92%
					COR10 - GELS RED 10	235	-	255	92%	-	100%
					no effect	0	-	9	0%	-	4%
					COG01 - GELS GREEN 1	10	-	34	4%	-	13%
					COG02 - GELS GREEN 2	35	-	59	14%	-	23%
					COG03 - GELS GREEN 3	60	-	84	24%	-	33%
					COG04 - GELS GREEN 4	85	-	109	33%	-	43%
12¹	-	-	green tone	step	COG05 - GELS GREEN 5	110	-	134	43%	-	53%
			J	'	COG06 - GELS GREEN 6	135	-	159	53%	-	62%
					COG07 - GELS GREEN 7	160	-	184	63%	-	72%
					COG08 - GELS GREEN 8	185	-	209	73%	-	82%
					COG09 - GELS GREEN 9	210	-	234	82%	-	92%
					COG10 - GELS GREEN 10	235	-	255	92%	-	100%
					no effect	0	-	9	0%	-	4%
					COB01 - GELS BLUE 1	10	-	34	4%	-	13%
					COB02 - GELS BLUE 2	35	-	59	14%	-	23%
					COB03 - GELS BLUE 3	60	-	84	24%	-	33%
					COB04 - GELS BLUE 4	85	-	109	33%	-	43%
13¹	-	-	blue tone	step	COB05 - GELS BLUE 5	110	-	134	43%	-	53%
					COB06 - GELS BLUE 6	135	-	159	53%	-	62%
					COB07 - GELS BLUE 7	160	-	184	63%	-	72%
					COB08 - GELS BLUE 8	185	-	209	73%	-	82%
					COB09 - GELS BLUE 9	210	-	234	82%	-	92%
					COB10 - GELS BLUE 10	235	-	255	92%	-	100%
					no effect	0	-	9	0%	-	4%
				step	2.700 K	10	-	30	4%	-	12%
				proportional	proportional value from 2.700 K to 3.200 K	31	-	52	12%	-	20%
				step	3.200 K	53	-	74	21%	-	29%
				proportional	proportional value from 3.200 K to 4.000 K	75	-	96	29%	-	38%
			1.	step	4.000 K	97	-	118	38%	-	46%
14	-	-	white tone	proportional	proportional value from 4.000 K to 5.000 K	119	-	140	47%	-	55%
				step	5.000 K	141	-	162	55%	-	64%
				proportional	proportional value from 5.000 K to 5.600 K	163	-	184	64%	-	72%
				step	5.600 K	185	-	206	73%	-	81%
				proportional	proportional value from 5.600 K to 6.500 K	207	-	228	81%	-	89%
				1 1	1 1					-	

				step	no effect	0	-	9	0%	Ī-	4%
		р		proportional	exalts the green color in the mixing and diminishes the presence of magenta	10	-	123	4%	-	48%
15³	-	-	green saturation	step	no effect	124	-	132	49%	-	52%
		proportional	diminishes the presence of green in the mixing and exalts the magenta color	133	-	246	52%	-	96%		
				step	no effect	247	-	255	97%	-	100%
164	-	-	saturation	proportional	the white tone fades to the tone built with the RGBWLA channels	0	-	255	0%	-	100%

**Note 1:** channels involving 11 - 12 - 13 macro colors can also be obtained by mixing channels 2 - 3 - 4 - 5 - 6 - 7.

Note 2: the one channel function mode can be selected through the "DMX SETTINGS" menu.

**Note 3:** the rest position of the green saturation is 128. Diminishing the DMX value augments the presence of the green color. Increasing the DMX value augments the presence of magenta.

**Note 4:** increasing the value of the saturation DMX channel the white tone (channel 14) will fade to the color selected by the channel 2 - 3 - 4 - 5 - 6 - 7.

Projector: LEDko FullSpectrum 6 HD	Chart name: DMX512 function	software version: 0.79 or
Edition: 6	<b>Date:</b> 24.05.2021	following

#### 8.2 DMX Chart Studio

channel	<b>function</b> master dimmer	el function ty	unction type of control	effect	de	ciı	mal	per	ntage
1		proportional	adjust luminous output intensity from 0 to 100%	0	-	255	0%	-	100%
			3.200 K	0	-	10	0%	-	4%
			2.700 K	11	-	16	4%	-	6%
			2.800 K	17	-	22	7%	-	9%
			2.900 K	23	-	28	9%	-	11%
			3.000 K	29	-	34	11%	-	13%
		-	3.100 K	35	-	40	14%	-	16%
			3.200 K	41	-	46	16%	-	18%
			3.300 K	47	-	52	18%	-	20%
			3.400 K	53	-	58	21%	-	23%
			3.500 K	59	-	64	23%	-	25%
			3.600 K	65	-	70	25%	-	27%
			3.700 K	71	-	76	28%	-	30%
			3.800 K	77	-	82	30%	-	32%
			3.900 K	83	-	88	33%	-	35%
			4.000 K	89	-	94	35%	-	37%
			4.100 K	95	-	100	37%	-	39%
			4.200 K	101	-	106	40%	-	42%
			4.300 K	107	-	112	42%	-	44%
			4.400 K	113	-	118	44%	-	46%
			4.500 K	119	-	124	47%	-	49%
2	white tone	step	4.600 K	125	-	130	49%	-	51%
			4.700 K	131	-	136	51%	-	53%
			4.800 K	137	-	142	54%	-	56%
			4.900 K	143	-	148	56%	-	58%
			5.000 K	149	-	154	58%	-	60%
			5.100 K	155	-	160	61%	-	63%
			5.200 K	161	-	166	63%	-	65%
			5.300 K	167	-	172	65%	-	67%
			5.400 K	173	-		68%	-	70%
			5.500 K	179	-	184	70%	-	72%
			5.600 K	185	-	190	73%	-	75%
			5.700 K	191	-	196	75%	-	77%
			5.800 K	197	-	202	77%	-	79%
			5.900 K	203	-	208	80%	-	82%
			6.000 K	209	-	214	82%	-	84%
			6.100 K	215	-	220	84%	-	86%
			6.200 K	221	-	226	87%	-	89%
			6.300 K	227	-	232	89%	-	91%
			6.400 K	233	-	238	91%	-	93%
			6.500 K	239	-		94%	-	96%
			5.600 K	245	-	255	96%	-	100%

			step no effect		no effect		0		0%		,
		proportional	exalts the green color in the mixing and diminishes the presence of magenta	1	-	127	0%	-	20%		
<b>3</b> ¹	green saturation	step	no effect	,	128		50%		%		
		proportional	diminishes the presence of green in the mixing and exalts the green color	129	-	254	51%	-	99%		
		step	no effect	2	25!	5	1	00	00%		
4	saturation	proportional	the white tone fades to the tone built with the HUE channel	0	-	255	0%	-	100%		
<b>5</b> <sup>2</sup>	hue	proportional	reproduce the color crossfades around the color space	0	-	255	0%	-	100%		
6	dimmer fine	proportional	fine dimmer control 16 bit	0	-	255	0%	-	100%		
			no effect	0	-	9	0%	-	4%		
			600 Hz	10	-	84	4%	-	33%		
		step	fan at low-noise speed	85	-	96	33%	-	38%		
			fan at studio mode	97	-	108	38%	-	42%		
7	special function		fan at auto-silent speed	109	-	120	43%	-	47%		
		proportional	fan speed control	121	-	133	47%	-	52%		
			enables the automatic display blackout	134	-	185	53%	-	73%		
		step	disables the automatic display blackout	186	-	199	73%	-	78%		
				no effect	200	-	255	78%	-	100%	

**Note 1:** the rest position of the green saturation is 128. Diminishing the DMX value augments the presence of the green color. Increasing the DMX value augments the presence of magenta.

**Note 2:** increasing the value of the saturation DMX channel (channel 4) the white light will fade to the color selected with the HUE channel (channel 5)

Projector: LEDko FullSpectrum 6 HD	<b>Chart name:</b> DMX512 function	software version: 0.79 or
Edition: 6	<b>Date:</b> 24.05.2021	following

#### 8.2 DMX RGB mode

channel	function	function type of control effect			cir	mal	percentage		
1	master dimmer	proportional	adjust luminous output intensity from 0 to 100%	0	-	255	0%	-	100%
2	dimmer fine	step	fine dimmer control 16 bit	0	-	255	0%	-	100%
3	red	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
4	green	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	55 0% -		100%
5	blue	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
		stop	no effect	0	-	9	0%	-	4%
		step	2.700 K	10	-	30	4%	-	12%
		proportional	proportional value from $2.700~\mathrm{K}$ to $3.200~\mathrm{K}$	31	-	52	12%	-	20%
		step	3.200 K	53	-	74	21%	-	29%
		proportional	proportional value from 3.200 K to 4.000 K	75	-	96	29%	-	38%
	1.5	step	4.000 K	97	-	118	38%	-	46%
6	white tone	proportional	proportional value from 4.000 K to 5.000 K	119	-	140	47%	-	55%
		step	5.000 K	141	-	162	55%	-	64%
		proportional	proportional value from 5.000 K to 5.600 K	163	-	184	64%	-	72%
		step	5.600 K	185	-	206	73%	-	81%
		proportional	proportional value from 5.600 K to 6.500 K	207	-	228	81%	-	89%
		step	6.500 K	229	-	255	90%	-	100%
<b>7</b> ¹	saturation proportional the white tone fade		the white tone fades to the tone built with the RGB channels	0	-	255	0%	-	100%
		step	no effect	0	-	9	0%	T-	4%
		proportional	variable speed strobing effect, from slow to fast	10	-	57	4%	-	22%
		step	stop strobe	58	-	59	23%	-	23%
		proportional	sequenced pulse effect, slow closing, fast opening (variable speed pulsing, from slow to fast)	60	-	108	24%	-	42%
		step	stop strobe	109	-	110	43%	-	43%
8	strobe	proportional	sequenced pulse effect, fast closing, slow opening (variable speed pulsing, from slow to fast)	111	-	159	44%	-	62%
		step	stop strobe	160	-	161	63%	-	63%
		proportional	random strobe effect with variable speed from slow to fast	162	-	207	64%	-	81%
		step	stop strobe	208	-	209	82%	-	82%
		proportional	random strobe effect with variable speed from slow to fast	210	-	255	82%	-	100%
			no effect	0	-	9	0%	-	4%
			600 Hz	10	-	84	4%	-	33%
		step	fan at low-noise speed	85	-	96	33%	-	38%
		3000	fan at studio mode	97		108	38%	+	42%
0	special				Ē			-	
9	function		fan at auto-silent speed	109	-	120	43%	-	47%
		proportional	fan speed control	121	-	133	47%	-	52%
			enables the automatic display blackout	134	-	185	53%	-	73%
		step	disables the automatic display blackout	186	-	199	73%	_	78%
			no effect	200	-	255	78%	-	100%

<b>Note 1:</b> ind 3, 4 or 5	reasing the value of the saturation DMX channel the white tone (channel 6) will fade to the color selected by the channel
	CI . DAAVE12

Projector: LEDko FullSpectrum 6 HD	<b>Chart name:</b> DMX512 function	software version: 0.79 or
Edition: 6	<b>Date:</b> 24.05.2021	following

#### 8.2 DMX fine RGB mode

channel	function	type of control	effect	de	cir	mal	per	cen	tage
	master dimmer	proportional	adjust luminous output intensity from 0 to 100%	0	-	255	0%	-	100%
2	dimmer fine	step	fine dimmer control 16 bit	0	-	255	0%	-	100%
3	red	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	100%
4	red fine	step	fine red control 16 bit	0	-	255	0%	-	100%
5	green	proportional	proportional control of the color percentage from 0 % to 100 %	0	-	255	0%	-	1009
6	green fine	step	fine green control 16 bit	0 - 255 0%		0%	-	1009	
7	blue	proportional	proportional control of the color percentage from 0 % to 100 %						1009
8	blue fine	step	fine blue control 16 bit	0	-	255	0%	-	1009
		step	no effect 2.700 K	0	-	9	0% 4%	-	4% 12%
		proportional	proportional value from 2.700 K to 3.200 K	31	-	52	12%	-	20%
5 6 7		step	3.200 K	53	-	74	21%	-	29%
		proportional	proportional value from 3.200 K to 4.000 K	75	-	96	29%	-	389
	1.	step	4.000 K	97	-	118	38%	-	469
	white tone	proportional	proportional value from 4.000 K to 5.000 K	119	-	140	47%	-	559
		step	5.000 K	141	-	162	55%	-	649
		proportional	proportional value from 5.000 K to 5.600 K	163	-	184	64%	-	729
		step	5.600 K	185	-	206	73%	-	819
		proportional	proportional value from 5.600 K to 6.500 K	207	-	228	81%	-	899
		step	6.500 K	229	-	255	90%	-	100
10¹	saturation	proportional	the white tone fades to the tone built with the RGB channels	0	-	255	0%	-	100
		step	no effect	0	-	9	0%	-	4%
		proportional	variable speed strobing effect, from slow to fast	10	-	57	4%	Ţ-	229
		step	stop strobe	58	-	59	23%	-	239
		proportional	sequenced pulse effect, slow closing, fast opening (variable speed pulsing, from slow to fast)	60	-	108	24%	-	42'
		step	stop strobe	109	_	110	43%	-	89% 100% 100% 4% 22% 23% 42% 43%
11	strobe	proportional	sequenced pulse effect, fast closing, slow opening (variable speed pulsing, from slow to fast)	111	_	159	44%	_	629
		step	stop strobe	160	-	161	63%	-	639
		proportional	random strobe effect with variable speed from slow to fast	162	-	207	64%	-	819
		step	stop strobe	208	<u> -</u>	209	82%	1-	829
		proportional	random strobe effect with variable speed from slow to fast	210	-	255	82%	-	100

			no effect	0	-	9	0%	-	4%
			600 Hz	10	-	84	4%	-	33%
		step	fan at low-noise speed	85	-	96	33%	-	38%
			fan at studio mode	97	-	108	38%	-	42%
12	special function		fan at auto-silent speed	109	-	120	43%	-	47%
	ranction	proportional	fan speed control	121	-	133	47%	-	52%
			enables the automatic display blackout	134	-	185	53%	-	73%
		step	disables the automatic display blackout	186	-	199	73%	-	78%
			no effect	200	-	255	78%	-	100%

**Note 1:** increasing the value of the saturation DMX channel the white tone (channel 6) will fade to the color selected by the channel 3, 4 or 5

Projector: LEDko FullSpectrum 6 HD	Chart name: DMX512 function	software version: 0.79 or
Edition: 6	<b>Date:</b> 24.05.2021	following

# 9. Display panel functions

#### 9.1 Quick guide to menu

To access the functions menus just press the MENU button. Then press + or – buttons to scroll the pages and press the ENTER button to access to any other function.

By suitably using all the functions of **LEDko FullSpectrum 6 HD**, which can be activated through its display panel, it is possible to change some of the parameters and to add some functions. Changing the preset settings made by **Coemar** can vary the functions of the projector so that it will respond differently to the controller; therefore carefully read about the functions described here before carrying out any possible selection.

#### 9.2 Rapid count

Through the display panel of **LEDko FullSpectrum 6 HD** it is possible to quickly change the various numbers displayed for the different functions in the following 3 manners:

- **1.** Pressing the + or buttons will cause the count to be quicker.
- 2. Pressing first + and then and then holding them down simultaneously will cause the numbers to jump to the highest value.
- **3.** Pressing first and then + and then holding them down simultaneously will cause the number to jump to the lowest value.


#### 9.3 Main functions menu

By pressing the Enter key "V" you can enter the LEDko FullSpectrum 6 HD's main menu.

#### exp dimming curve **Dimming curve:** log It allows the selection of different dimmer curves: linear, exponential (default) and logalinear rithmic on Halogen off Halogen: Simulates a halogen curve by inserting a softening of the dimmer dynamics and red shift. It works only for CCT 3000 K and 3200 K dmx personality dmx settings It is possible to choose between 16, 7, 1 channels, Studio, RGB, RGB fine, in which the projector will work **DMX settings:** Manually sets the strobe DMX channel wireless dmx signal loss It is possible to choose between "maintain" (this function allows to keep the settings even in case of loss of signal) and "blackout" (in case of loss of signal, the projector will go into blackout) automatic fan mode Fan with automatic operating speed to guaran-Fan mode: tee maximum light output in all conditions of use, ideal for live events, exhibitions and archi-Manually sets the fan mode tectural installations. studio Fan at automatic operation speed with limited speed to guarantee silent operation of the product (moderately limited light output, will decrease in case of overheat) ideal for broadcast or theatre applications. low noise This setting will keep the speed of the fan at the

minimum level (moderately limited light output, will decrease in case of overheat) ideal for envi-

ronments that require maximum silence.



#### 9.4 Measures

#### temperature

#### Temperature:

Shows the current temperature values of the fixture

**BOARD** LED -°C **\_°**( NOW: **-°**C **-°**C MIN: **-°**C **-°**C MAX: history **-°**C -°C NOW: MIN: **-°**C **-°**C MAX: **\_°**C **-°**C

**LED:** shows the LED module temperature; **Board:** shows the electronic board temperature

**History:** shows the history temperature of the LED and electronic board temperature

#### **PSU VOLTAGE**

#### **PSU Voltage:**

Shows the power supply voltage

#### fan level

#### Fan level:

Shows the percentage fan usage

# Level: -% voltage: -V

rotation: -rpm

#### dmx refresh rate

#### **DMX Refresh Rate:**

Shows the refresh rate of the DMX signal sent by the console

#### dmx input

#### **DMX Input:**

Shows the value of the DMX channels received by the fixture on every channel that the fixture occupies on the line

#### led status

#### **LED status:**

Shows the percentage value of the LED status

# red: -% green: -% blue: -% white: -% lime: -% amber: -%

**Note:** under the heading protection will always be displayed the value 100% unless the headlight is overheated and then goes to the point of protection

#### fixture lifetime

#### **Fixture lifetime:**

Shows the hour counter of the fixture

unit life: 
LED life: 
module life: -

**Unit life:** shows the overall hours of life of the fixture:

**LED life:** shows the overall LED module life; **Module life:** shows the overall LED module life currently installed.

**Note:** this items can be reset in case of LED module replacement;

#### alarm

#### Alarm:

This menu eventually shows the alarm statuses if there is any (see page 28)

#### firmware version

#### **Firmware version:**

Shows the firmware version currently installed in the fixture

#### 9.5 Color presets

By pressing the **color preset** button "O", on the rear panel, you can enter the LEDko FullSpectrum 6 HD's main menu.

# intensity

#### Intensity:

allows adjust luminous output intensity

#### white tone gels

#### White tone gels:

This channel offers a preset library of various white CCT with a range that goes from 2700 K and up to 6500 K, manually selectable without the need of a DMX console

2700 K

3000 K

3200 K

3500 K

4000 K

4500 K

5000 K

5500 K

5600 K


6000 K


6500 K

green saturation

#### **Green saturation:**

Once the color temperature is selected, the green saturation function will automatically be activated, which allows to increase or decrease the presence of green and magenta





Performs an increasing and decreasing simulation of the dimmer

# **9.6** Special functions of the fixture Storing the DMX signal

To use the fixture without an active DMX console it is possible to store the DMX settings in two ways:

- · Through the menu;
- Disconnecting the DMX signal when the fixture is on. When the signal is unconnected the fixtures stores the signal;

#### **Automatic fan standby**

To decrease the noise and the power consumption the cooling fan turns off after 10 minutes of fixture inactivity.

#### 9.7 Error messages

If a malfunction occurs, **LEDko FullSpectrum 6 HD** has a self-diagnostic system that will show the error message on the display. The following table will explain in detail the most common errors. If, despite of suggested intervention, the problem persists, call the **Coemar** Service Center.

Error code	Description					
Data Error	<b>Data error</b> Initial data loading has failed the projector loaded the default data settings: restart the fixture again, and if the error persists contact the <b>Coemar</b> assistance center.					
Address Error	Address error  The projector does not receive all channels of DMX needs to function properly. Check the DMX address indicated on the display and the number of channels generated by the mixer control. We recall in this connection that some controllers do not generate all the 512 channels.					
sensor not detected	<b>Sensor not detected</b> LED temperature sensor missing or damaged.					
sensor shorted	<b>Sensor shorted</b> Error of the LED's sensor circuit.					
fan not rotating	Fan not rotating  Auto diagnostic routine found that the Fan may be damaged, contact Coemar assistance for the module replacement.  IMPORTANT: To ensure the sensor is giving correct readings or that the fan rotates correctly, set the fan to the maximum level.					

# 10. Accessories and spare parts

is a very versatile fixture, optional accessories for its customization are available under request:

Accessory name	Code
Front barrel for lens tube with burnished blades	BC10011A200
Profile 5°, lens tube	BC10011A041
Profile 10°, lens tube	BC10011A042
Profile 14°, lens tube	BC10011A023
Profile 19°, lens tube	BC10011A012
Profile 26°, lens tube	BC10011A013
Profile 36°, lens tube	BC10011A015
Profile 50°, lens tube	BC10011A016
Profile 70°, lens tube	BC10011A024
Profile 90°, lens tube	BC10011A025
Profile Zoom 15°- 35°	BC10011A017
Profile Zoom 25°- 50°	BC10011A019
Profile Zoom 28°- 40°	BC10011A003
Soft Profile Fresnel Zoom 14°- 40°	BC10011A002
Soft Profile PC Zoom 11°- 38°	BC10011A001
4 leaf barndoor	AC04202
Gobo frame holder	BC10011A006
Iris	BC10011A010
Donut (190.5 mm)	BC10011A028
Half Top Hat (190.5 mm)	BC10011A027
Top Hat (190.5 mm)	BC10011A029
Color Frame Holder (190 mm)	BC10011A040
Donut (185 mm)	BC10011A036
Half Top Hat (185 mm)	BC10011A035
Top Hat (185 mm)	BC10011A037
Color Frame Holder (185 mm)	AC04204

Donut (159 mm)	BC10011A032
Half Top Hat (159 mm)	BC10011A031
Top Hat (159 mm)	BC10011A033
Colour Frame Holder (159 mm)	BC10011A021
(Gobo Slot) Glass template holder (93.6 mm)	BC10011A030
Hook clamp, 48-51 mm, max. load 20 Kg.	BC10011A047
Light clamp silver, 48-51 mm, max. load 75 Kg.	BC10011A045
Light clamp black, 48-51 mm, max. load 75 Kg.	BC10011A046
Clamp silver, flat 13-30 mm/ø 15-50 mm, max. load 20 Kg.	BC10011A043
Clamp black, flat 13-30 mm/ø 15-50 mm, max. load 20 Kg.	BC10011A044

All the components of **LEDko FullSpectrum 6 HD** are available as spare parts from your Coemar dealer or Service. Accurate description of the fixture, model number and type will assist us in providing for your requirements in an efficient and effective manner.

## 11. Maintenance

#### **11.1** Firmware update

The firmware of **LEDko FullSpectrum 6 HD** can be updates through the RDM protocol (ANSI E1.20). Contact Coemar assistance to receive the software and the device updater.

#### 11.2 Periodic cleaning

#### Lenses

Even a thin layer of dust can reduce the luminous output and alter the consistency of the beam. Regularly clean all filters and lenses using a soft cotton cloth, dampened with a special lens cleaning solution.

#### Cleaning of the unit

Use a soft brush or a common vacuum cleaner or a source of compressed air for removing dust. For the cleaning of the housing use a soft cloth and a non-aggressive cleaner. Check that the internal fans and heat exchanger must be perfectly clean.

#### 11.3 Periodic controls

#### **Mechanical components**

Check the correct working of the mechanical parts and, if needed, replace them. Make sure the projector is not mechanically damaged. If necessary, replace the worn parts.

#### **Electrical components**

Check all electrical connections, in particular for correct grounding and correct attachment of all extractable connectors. Press the connectors if necessary and reposition as before.

#### **11.4** Fuses

**LEDko FullSpectrum 6 HD** has an automatic fuse that in most cases does not need to be replaced.


# 12. F.A.Q. and answers

The following list shows common issues that may be simply solved. If issues persist, the unit must be repaired by a qualified personnel or just contact your **Coemar** service near you.

Question	Possible solution
<b>LEDko FullSpectrum 6 HD</b> does not emit light	<ul> <li>Projector not powered on:</li> <li>Make sure the power cord is plugged in or test the input voltage;</li> <li>Wrong DMX address:</li> <li>Check the DMX Address setting and the output signal of the controller;</li> </ul>
<b>LEDko FullSpectrum 6 HD</b> is not responding to DMX signal	<ul> <li>DMX signal may not reach LEDko FullSpectrum 6 HD:</li> <li>Inspect the cable connection, correct poor connections or inefficient repair or replace damaged cables;</li> <li>Check DMX address of the unit;</li> </ul>

# **User notes**

	••••				••••	• • • • •			••••	• • • • •		• • • • •							
• • • • • •	••••	• • • •	• • • • •	• • • • •	••••	• • • • •	• • • • •	• • • •	••••	• • • • •	••••	• • • • •	• • • • •	• • • • •	• • • • •	• • • • •	• • • • •		• • • • •
• • • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •	• • • • •	• • • •	• • • •	• • • • •	• • • •	• • • • •	• • • • •	• • • • •	• • • • •	• • • • •	• • • • •	• • • •	• • • • •
					• • • •														
	••••		••••		••••			• • • •											
• • • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •	• • • • •		• • • •	• • • • •		• • • • •	• • • • •		• • • • •	• • • • •	• • • • •		• • • • •
• • • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •		• • • •	••••	• • • • •	• • • •	• • • • •			• • • • •	• • • • •	• • • • •	• • • • •	• • • • •
• • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •	• • • • •		• • • •	• • • • •		• • • • •	• • • • •		• • • • •	• • • • •	• • • • •		• • • • •
• • • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •			• • • •	• • • • •		• • • • •	• • • • •		• • • • •	• • • • •	• • • • •		• • • • •
	<b></b>			<b></b>			<b></b>	<b></b>				<b></b>							
• • • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •		• • • •	••••	• • • • •		• • • • •	• • • • •		• • • • •	• • • • •	• • • • •	• • • • •	• • • • •
	• • • •	• • • •	• • • •	• • • • •	• • • •	• • • • •				• • • • •		• • • • •	• • • • •		• • • • •	• • • • •	• • • • •		• • • • •
• • • • • •	••••	• • • •	• • • • •		• • • •	• • • • •			••••	• • • • •	• • • •	• • • • •	• • • • •		• • • • •	• • • • •	• • • • •		• • • • •
	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •	• • • • •		• • • •	• • • • •		• • • • •	• • • • •		• • • • •	• • • • •	• • • • •		• • • • •
																			:
							• •									· · · · ·			
• • • • • •	• • • •	• • • •	• • • • •	• • • • •	• • • •	• • • • •	• • • • •	• • • •	• • • •	• • • • •		• • • • •	• • • • •	• • • • •	• • • • •	• • • • •	• • • • •		• • • • •





**Coemar Lighting s.r.l.** Via Carpenedolo 90 46043 Castiglione delle Stiviere, Mantova, Italy phone. +39 0376/1514412 - fax +39 0376/1514380 info@coemar.com

**Coemar** reserves the right to effect modifications without notification