


How to mount Pole Operated yoke on LEDko

Once you have taken your projector, proceed with disassembling the standard yoke, unscrewing the screws on both sides (figure A).



At this point, take the Pole Operated yoke and, after checking that the Pole Operated “pivot housing” (figure B) is in line with the plate to which the yoke will be fixed, screw the two supplied screws (figure C).

Be careful when inserting screws, do not apply too much pressure to avoid dropping the nut fixed inside the projector.

