

How to use a standard clamp with the MiniLEDko Portable

To use a standard clamp you need to change the screw in order to match it with the MiniLEDko. As shown in the photos below pull away the screw and replace it with a screw **M8** with a length of **24 mm (0.95 in)**

